

| PARTS NAME 零件名称 | | PARTS CODE 零件编号 |
|--|---------------|-----------------|
| | | Type - M |
| Barrel and train wheel bridge | 轮列夹板 | 0112 427 |
| Center wheel bridge | 中心轮夹板 | 0121 422 |
| Pallet bridge | 擒纵叉(马仔)夹板 | 0161 420 |
| Balance bridge | 油丝夹板 | 0173 426 |
| Lower plate for balance bridge | 油丝夹板下板 | 0105 421 |
| Balance complete with stud | 油丝连夹板含外桩 | 0310 421 |
| Framework for automatic device with ball bearing | 自动锤夹板 | 0193 207 |
| Complete barrel with mainspring | 条盒轮(发条鼓) | 0201 420 |
| Center wheel and pinion | 中心轮 | 0224 425 |
| Cannon pinion | 分轮(十反) | 0225 422 |
| Third wheel and pinion | 3# 轮 | 0231 421 |
| Fourth wheel and pinion | 4# 轮(秒轮) | 0241 421 |
| Escape wheel and pinion | 擒纵轮(莲花轮) | 0251 420 |
| Minute wheel and pinion | 度数轮 | 0261 422 |
| Center seconds pinion | 秒轴 | 0245 425 |
| Hour wheel | 时轮 | 0271 425 |
| Clutch wheel | 离合轮 | 0282 422 |
| Winding pinion | 企轮 | 0283 421 |
| Ratchet wheel | 大钢轮 | 0285 420 |
| Intermediate ratchet wheel | 大钢轮中间轮 | 0237 421 |
| Rocking sheet for sliding crown wheel | 游动坐 | 0542 421 |
| Pallet fork | 擒纵叉(马仔) | 0301 420 |
| Sliding crown wheel spring | 游动坐弹弓 | 0363 420 |
| Click | 止逆爪(上鍊弹弓) | 0381 420 |
| Setting lever | 设置杆(压制) | 0383 420 |
| Yoke | 离合杆(横担) | 0384 207 |
| Setting lever spring | 设置杆弹弓(压制掩) | 0388 420 |
| Setting lever axle | 设置杆轴(压制柱) | 0390 421 |
| Friction spring for center seconds pinion | 秒轴压片(秒针掩) | 0396 421 |
| Reduction wheel and pinion | 自动轮(逆轮) | 0505 207 |
| Pawl lever | 自动叉 | 0831 207 |
| Date indicator driving wheel | 日送轮 | 0802 423 |
| Date indicator finger | 日送轮(日送爪) | 0556 423 |
| Date indicator maintaining plate | 日历定位片(日历盘压片) | 0808 424 |
| Date jumper | 日历定位弹弓 | 0810 420 |
| Date jumper spring | 日历定位杆弹弓 | 0811 420 |
| Intermediate date driving wheel and pinion | 日送中间轮 | 0817 421 |
| Day-date corrector finger | 日历星期修正爪 | 0972 423 |
| Dial support | 面圈 | 0884 172 |
| Barrel and train wheel bridge screw (A) | 轮列夹板(大夹板)螺丝 A | 0012 484 |
| Barrel and train wheel bridge screw (B) | 轮列夹板(大夹板)螺丝 B | 0012 485 |
| Center wheel bridge screw | 中心轮夹板螺丝 | 0012 485 |
| Pallet bridge screw | 擒纵叉(马仔)夹板螺丝 | 0012 485 |
| Balance bridge screw | 油丝夹板螺丝 | 0012 484 |
| Framework for automatic device screw | 自动锤夹板螺丝 | 0012 485 |
| Setting lever spring screw | 设置杆弹弓螺丝 | 0012 484 |
| Date indicator driving wheel screw | 日送轮螺丝 | 0016 139 |
| Date indicator maintaining plate screw | 日历定位片螺丝 | 0012 485 |
| Oscillating weight (without pinion) screw | 自动锤螺丝 | 0012 488 |
| Screw for rocking sheet for sliding crown wheel | 游动坐螺丝 | 0012 484 |
| Winding Stem | 巴芯 | 0351 247 |