

※Please contact us when you order these parts. ※订购零件时请与我们联系

PARTS CODE 零件编号

| PARTS NAME 零件名称 | | PARTS CODE 零件编号 | |
|---|---------------|-----------------|------------------|
| | | Type - M | Type - L - LA |
| Train wheel bridge | 轮列夹板 | 0125 406 | |
| Center wheel bridge | 中心轮夹板 | 0121 060 | |
| Center wheel and pinion | 中心轮 | 0221 089 | ※ |
| Third wheel and pinion | 3# 轮 | 0231 061 | |
| Fourth wheel and pinion | 4# 轮 (1/4秒行针) | 0144 004 | ※ |
| Fifth wheel and pinion | 5#轮 | 0701 017 | |
| Sixth wheel and pinion | 6#轮 | 0706 008 | |
| Step rotor | 磁石轮 | 4146 104 | |
| Hour wheel | 时轮 | 0273 043 | ※ |
| Minute wheel and pinion | 度数轮 | 0261 052 | |
| Setting wheel | 小铁车 | 0281 015 | |
| Clutch wheel | 离合轮 | 0282 452 | |
| Setting lever | 设置杆 (压制) | 0383 154 | |
| Yoke | 离合杆 (横担) | 0384 452 | |
| Train wheel setting lever | 规正弹弓 | 0391 029 | |
| Stator | 定子板 | 4239 065 | |
| Friction spring for fourth wheel and pinion | 秒轴压片 | 0560 005 | |
| Circuit block | 回路板 | 4004 474 | |
| Coil block | 线圈 | 4002 071 | |
| Battery connection(+) | 正极片 (+) | 4268 146 | ※ |
| Battery connection(-) | 负极片 (-) | 4270 339 | |
| Insulator | 绝缘片 | 4216 103 | |
| Date driving wheel | 日送轮 | 0802 469 | |
| Intermediate wheel for date corrector (A) | 日历修正中间轮 (A) | 0804 169 | |
| Small hour hand wheel | 小时针轮 | 0157 018 | ※ |
| Support for dial side parts | 日历星期弹弓片 | 0604 015 | |
| Dial washer | 针座/金片 | 0491 014 | |
| Battery connection(+) screw | 正极片 (+) 螺丝 | 0012 168 | |
| Support for dial side parts screw | 日历星期弹弓片螺丝 | 0012 354 | |
| Center wheel bridge screw | 中心轮夹板螺丝 | 0012 354 | |
| Coil block screw | 线圈组螺丝 | 0012 354 | |
| Winding Stem (TYPE A) | 巴芯 | 0351 177 | |
| Winding Stem (TYPE B) | 巴芯 | 0351 122 | |